

Factory Five Racing, Inc.

Part Number: 15504 Revision: A Effective Date: 6/4/12 By: J. INGERSLEV

Document Type (indicate):

° Bill of Material

Bill of Material
 Drawing (may be attached)
 Specification
 Assembly Instructions
 Operating Procedure
 Other

Coyote Headers

Installation Instructions

- \$\forall 15mm, 17mm sockets, 15mm wrench
- **⇒** Coyote headers
- The threads in the heads for the headers changed a couple times during production Be careful when installing the headers bolts so the threads are not ruined. After removing the headers studs, compare the thread to the new header bolts.

Production header bolt change dates: From 3-22-10 to 9-8-10 M10 x 1.50 Coarse From 9-8-10 to 1-18-11 M10 x 1.25 Fine From 1-18-11 M10 x 1.50 Coarse

FFR supplies the course bolts only. If the fine thread bolts are needed, the specifications you require when you purchase the bolts are: M10 x 1.25mm x 25mm long grade 8.8 hex head bolt

Attach the headers to the engine by inserting and tighten all of the bolts by hand before tightening any with a wrench.

Hot Rod

