



Factory Five Racing, Inc.

Part Number: 14933

Revision: B

Effective Date: 2/6/19

By: J. Ingerslev

Halibrand style wheels Installation Instructions

The threaded Adapters and tri wings are left and right hand threaded. The Right hand threaded parts must be fitted to the left hand of the vehicle (U.S. Driver side). The Left hand threaded parts must be fitted to the right hand side of the vehicle (U.S. Passenger side).

Wheel mounting:

1. Put some anti seize on the adapter threads.
2. Insert the correct adapter from the back side of the wheel into the center of the wheel.
3. Hold the adapter from the front side of the wheel when mounting the wheel on the car.
4. Tighten the lug nuts on the car.
5. Push the lug nut cover onto the adapter covering the wheel lugs.
6. Spin the correct Tri wing onto the adapter so it is hand tight.
7. Tighten the set screw on the side of the Tri wing so that it just touches the threads. Not a lot of pressure is required. The set screw is a secondary safety measure to prevent the tri wing from coming off the wheel. Fitting the correct threaded adapter and tri wing to the correct side of the car is very important.