

Parts required to complete:

Per Transport Canada, these parts need to be ordered separately from the kit.

Whitby Motorcars in Greensboro, NC. Whitby Motorcars can be reached at:

(336)-373-0835

www.whitbymotorcars.com

whitbymotorcars@aol.com

818 Completion Pack (Choose one of the following)

80740 818 Turbo Completion Pack
80761 818 N/A Completion Pack

818 Options:

80711 Koni Double Adjustable Shocks
80730 Adjustable Rear Lower Control Arms
80800 818 Wilwood Pedalbox
81096 05-07 Complete CV Axles
81097 02-04 Complete CV Axles

Optional Brakes:

Wilwood Brake Upgrades: Wilwood Brakes are available with either **red** or **black** calipers and a **drilled & slotted** rotor configuration.

*These brakes are drop shipped directly from Wilwood

80653 13.00" Front Wilwood Brakes, Red Calipers, Drilled & Slotted
80654 12.88" Rear Wilwood Brakes, Red Calipers, Drilled & Slotted

80650 13.00" Front Wilwood Brakes, Black Calipers, Drilled & Slotted
80651 12.88" Rear Wilwood Brakes, Black Calipers, Drilled & Slotted

80665 12.00" Front Wilwood Brakes, Red Calipers, Drilled & Slotted
80666 12.18" Rear Wilwood Brakes, Red Calipers, Drilled & Slotted

80662 12.00" Front Wilwood Brakes, Black Calipers, Drilled & Slotted
80663 12.18" Rear Wilwood Brakes, Black Calipers, Drilled & Slotted